

BLANCO











Reparatur-Anleitung
Repair instruction






BLANCO SORA HD




BLANCO

BLANCO SORA








30 mm





Art.-No. 139 181





BLANCO

BLANCO SORA





⊗





⊗ 2,5 mm

Art.-No. 139 188




⊗ 12 mm








12 mm



2,5 mm

Art.-No. 139 188



BLANCO

BLANCO SORA

